



# PAC SHOUDLER BAG OPTIONS

lock loop -tube holders- pump holders

## THE LOCK LOOP

The lock loop option is comprised of two parts, the lock loop square; which is sewn onto the bags base, and the thick webbing Lock loop. The loop comes adjusted for a medium sized lock; you will probably have to adjust the loop to fit your own lock. Slide the lock loop around so that the buckles adjusting can be accessed. Tighten or loosen it around your lock so that there is a bit of play but not too much that your lock can slide through.

Once you have the right adjustment slide the lock loop back around so that the buckle is hidden behind the lock loop square.

## TUBE HOLDERS

Tube holders can be used to attach things to the outside of your bag through the upper or lower 1 or 2-inch "D" rings. They can be used to hold your jacket, tubes, or whatever. You may have to unsnap the wagging reflective tail to get the tube holder threaded through the 1-inch bottom "D" ring. The tube holders can also be used like industrial elastics to hold things together inside your bag.

## PUMP HOLDERS

The Pump holders have been designed to attach to the bottom of the Ultimate expandable pocket. They should fit just about any pump and have about an inch of adjustment. If you wish you can remove the pump holders from the bottom of the pocket.



LOCK LOOP ON BAG



ADJUSTING LOCK LOOP



SIZING LOCK LOOP



TUBE HOLDERS



TUBE HOLDERS ON UPPER "D" RINGS



TUBE HOLDERS ON BOTTOM D RINGS



TUBE HOLDERS SECURING LETTERS



PUMP HOLDERS



PUMP HOLDERS BOTTOM OF BAG